EQL SURFACE MOUNT INSTALLATION INSTRUCTIONS




TO BE INSTALLED BY A QUALIFIED ELECTRICIAN IN **ACCORDANCE TO LOCAL &** NATIONAL ELECTRIC CODES



LEDS ARE EASILY DAMAGED. AVOID CONTACT WHEN INSTALLING AND SERVICING.



DAY-O-LITE ASSUMES NO RESPONSIBILITIES FOR CLAIMS FOUNDED FROM IMPROPER INSTALLATION OR HANDLING.





RISK OF ELECTRICAL SHOCK. DISCONNECT POWER BEFORE INSTALLATION OR SERVICING


0



RISK OF BURN, DO NOT TOUCH LED DIODE OR DRIVER WHEN SERVICING. ALLOW TO COOL BEFORE HANDLING.








1. REMOVE LENS RING FROM FIXTURE, TWIST LENS RING COUNTERCLOCKWISE AND PULL AWAY FROM FIXTURE.

USE CAUTION TO NOT DROP LENS. LENS RING IS EASILY DENTED, HANDLE WITH CARE!

- 2. REMOVE DRIVER COVER FROM FIXTURE
- 3. PUSH SUPPLY WIRE (BY OTHERS) THROUGH HOLE IN CENTER OF FIXTURE. BE SURE TO ALLOW ENOUGH WIRE TO MAKE CONNECTIONS. SECURE FIXTURE TO CEILING USING APPROPRIATE HARDWARE (BY OTHERS)
- 4. CONNECT SUPPLY WIRES AND FIXTURE WIRES USING APPROPRIATE CONNECTOR PER LOCAL ELECTRICAL CODES. STANDARD WIRING DIAGRAM SHOWN, REFER TO JOB DRAWINGS FOR JOB SPECIFIC WIRING
- 5. RE-INSTALL DRIVER COVER
- 6. RE-NSTALL LENS BY LIFTING ONTO FIXTURE AND TURNING COUNTER-CLOCKWISE UNTIL SECURE
- 7. INSTALLATION IS COMPLETE



MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN, DISCONNECT POWER DURING INSTALLATION/SERVICING, ROW CONFIGURATION IS JOB SPECIFIC, CONSULT SHOP DRAWINGS BEFORE CONSTRUCTING ROWS, STANDARD OPTIONS/SIZES SHOWN, OTHER OPTIONS AVAILABLE WITH SIMILAIR INSTALLATION. BE SURE TO UNDERSTAND ALL PROCEDURES PRIOR TO INSTALLATION. IMPORTANT: THE NATIONAL ELECTRIC CODE REQUIRES THAT ANY FIXTURE IN EXCESS OF 50 POUNDS MUST BE INDEPENDENTLY SUPPORTED OF THE OUTLET BOX. DAY-O-LITE IS NOT RESPONSIBLE FOR INADEQUATE REINFORCEMENT OF STRUCTURAL SUPPORT SYSTEMS, DAY-O-LITE RESERVES THE RIGHT TO MAKE ANY MECHANICAL OR MATERIAL CHANGES TO THE FIXTURES WHICH DO NOT AFFECT THE APPEARANCE OR PERFORMANCE, THIS PRINT IS THE PROPERTY OF DAY-O-LITE AND THE INFORMATION IT CONTAINS MAY NOT BE USED WITHOUT WRITTEN CONSENT OF DAY-O-LITE.

MODEL NO.: PAGE: EQL-PND----SHEET 1 OF 2 CONTACT INFORMATION:

126 Chestnut Street, Warwick, RI 02888 Tel. (401) 467-8232 Fax. (401) 941-2960 E-mail: sales@davolite.com WWW: http://www.dayolite.com




970109A0


ISSUED ON:


9/9/2020


EQL SURFACE MOUNT INSTALLATION INSTRUCTIONS

















LEDS ARE EASILY DAMAGED, AVOID CONTACT WHEN INSTALLING AND SERVICING.



FAILURE TO COMPLY TO
INSTRUCTIONS &
FORMENTIONED WARNINGS
COULD VOID PRODUCT
WARRANTY



S JOB
ILE EQL-PND---ECTRIC CONTACT INFORMATION:

126 Chestnut Street, Warwick, RI 02888

Tel. (401) 467-8232 I Fax. (401) 941-2960
E-mail: sales@dayolite.com

WWW: http://www.dayolite.com

Lighting Without Limits

970109A0

MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN. DISCONNECT POWER DURING INSTALLATION/SERVICING. ROW CONFIGURATION IS JOB SPECIFIC, CONSULT SHOP DRAWINGS BEFORE CONSTRUCTING ROWS. STANDARD OPTIONS/SIZES SHOWN, OTHER OPTIONS AVAILABLE WITH SIMILAIR INSTALLATION. BE SURE TO UNDERSTAND ALL PROCEDURES PRIOR TO INSTALLATION. IMPORTANT: THE NATIONAL ELECTRIC CODE REQUIRES THAT ANY FIXTURE IN EXCESS OF 50 POUNDS MUST BE INDEPENDENTLY SUPPORTED OF THE OUTLET BOX. DAY-O-LITE IS NOT RESPONSIBLE FOR INADEQUATE REINFORCEMENT OF STRUCTURAL SUPPORT SYSTEMS. DAY-O-LITE RESERVES THE RIGHT TO MAKE ANY MECHANICAL OR MATERIAL CHANGES TO THE FIXTURES WHICH DO NOT AFFECT THE APPEARANCE OR PERFORMANCE. THIS PRINT IS THE PROPERTY OF DAY-O-LITE AND THE INFORMATION IT CONTAINS MAY NOT BE USED WITHOUT WRITTEN CONSENT OF DAY-O-LITE.