HML/HML2 ACY MOUNT INSTALLATION




RISK OF ELECTRICAL SHOCK.
DISCONNECT POWER BEFORE INSTALLATION OR








COULD VOID PRODUCT FORMENTIONED WARNINGS INSTRUCTIONS & FAILURE TO COMPLY TO





1. HANG FIXTURE. INSTALL A/C-Y CABLE AS SHOWN. LIFT FIXTURE INTO POSITION AND FEED A/C CABLE THROUGH CABLE GRIPPER. TIGHTEN CABLE GRIPPER IN

2. INSTALL (4) #8 SCREW TO THE FIXTURE HOUSING CABLE SLOT LOCATION .FEED POWER FEED CORD THROUGH HOLE IN FIXTURE. USE APPROPRIATE STRAIN RELIEF TO SECURE CORD IN FIXTURE AS REQUIRED BY LOCAL ELECTRICAL CODES. CUT END FROM HARNESS AND CONNECT POWER FEED CONDUCTORS TO APPROPRIATE DRAWINGS FOR JOB SPECIFIC WIRING WIRES OF WIRE HARNESS. STANDARD WIRING DIAGRAM SHOWN, REFER TO JOB

SPECIFIC, CONSULT SHOP DRAWINGS BEFORE CONSTRUCTING ROWS. STANDARD OPTIONS/SIZES SHOWN, OTHER OPTIONS AVAILABLE WITH SIMILAIR INSTALLATION. BE SURE TO UNDERSTAND ALL PROCEDURES PRIOR TO INSTALLATION. IMPORTANT: THE NATIONAL ELECTRIC CODE REQUIRES THAT ANY FIXTURE IN EXCESS OF 50 POUNDS MUST BE INDEPENDENTLY SUPPORTED OF THE OUTLET BOX. DAY-O-LITE IS NOT RESPONSIBLE FOR INADEQUATE REINFORCEMENT OF STRUCTURAL SUPPORT SYSTEMS. DAY-O-LITE RESERVES THE RIGHT TO MAKE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN. DISCONNECT POWER DURING INSTALLATION/SERVICING. ROW CONFIGURATION IS JOB THE PROPERTY OF DAY-O-LITE AND THE INFORMATION IT CONTAINS MAY NOT BE USED WITHOUT WRITTEN CONSENT OF DAY-O-LITE. ANY MECHANICAL OR MATERIAL CHANGES TO THE FIXTURES WHICH DO NOT AFFECT THE APPEARANCE OR PERFORMANCE. THIS PRINT IS

,		
	HML2-ACY	MODEL NO.:

SHEET 1 OF 1

5/14/24

PART NUMBER: **970181A0** ISSUED ON

0

CONTACT INFORMATION: Tel. (401) 467-8232 | Fax. (401) 941-2960 126 Chestnut Street, Warwick, RI 02888

E-mail: sales@dayolite.com WWW: http://www.dayolite.com

